voltage-mode operation It is possible to operate the current multiplying D/A converter of these devices in a voltage mode. In the voltage

mode.

(Analog Output Voltage)

mode, a fixed voltage is placed on the current output terminal. The analog output voltage is then available at the reference voltage terminal. Figure 11 is an example of a current multiplying D/A that operates in the voltage

Out (Fixed Input Voltage)

AGND

Figure 11. Voltage-Mode Operation

2R

2R

The following equation shows the relationship between the fixed input voltage and the analog output voltage: $V_O = V_I (D/256)$